


# SPECIAL *Event* RENTALS

## Money Machine Instructions


1. Assemble two squares using 4 unswaged pipes and 4 coner fitterings for each




2. Insert swaged pipes into each corner of one square and the remaining unswaged pipes into the four corners of the other square



3. Turn the two cubes onto their sides and slide them together



4. Attach the vinyl booth while the unit is lying in it's side, them tip it into it's upright position



### Packing List

DESCRIPTION	QUANTITY
VINYL BOOTH.....	1
"THREE-WAY" FITTINGS.....	8
LENGTHS OF TUBING (SWEDGED) .....	4
LENGTHS OF TUBING (UNSWEDGED)...	12
BLOWER.....	1
SAFETY GOGGLES .....	1
TOP.....	1
PIPE CASE .....	1
BOOTH CASE.....	1

<p><b>Edmonton</b> 780-435-2211 6010-99 Street</p>	<p><b>Red Deer</b> 403-347-7733 5929-48 Ave</p>	<p><b>Calgary</b> 403-235-2211 2312-52 Ave</p>	<p><b>Banff</b> 403-762-2227 150 Eagle Crescent</p>
--	---	--	---

## **Safety Instructions**

1. Do not use the blower near water, or plug it in if it is wet.
- 2. NEVER USE THE GAME IN STRONG WINDS OR LIGHTENING**
3. Use caution when setting up or taking down the game. Once the bolts are loosened the sections of tubing can come apart and fall down causing injury.
4. Be sure players wear the safety goggles inside the booth. Keep spectators away from the blower.
5. Secure power cord to avoid a trip-hazard.

## **Suggested Rules**

1. Players must remove shoes and put on goggles before entering.
2. Player must not begin collecting bills until the operator says, "Go!"
3. The player must stop collecting bills when the operator says, "Stop!"
4. When the operator turns on the blower, he/she should allow a few seconds for the bills to start circulating before giving the "go" signal.
5. The player must remove the bills from the air. He/She may not take bills off of the floor, ceiling, walls or off of their own body.
6. The operator may or may not supply a collection pouch for the bills, depending on the amount of bills they wish to give away. (Obviously, if the play can only keep what he/she can hold in their hands, fewer bills will be awarded.)
7. The operator may use real cash, play money, a mixture of real/play money, coupons, tickets, etc.
8. Crumpled bills circulate better than crisp or flat bills. Therefore, you may wish to keep crumpled bills inside the unit and replace them with an equal amount of fresh ones for each player as they exit.

## **Instructions for Care**

1. Do not store unit damp.
2. Do not store vinyl in the same case with pipes or fittings.
3. Periodically check electrical wire for wear.

### **Edmonton**

780-435-2211  
6010-99 Street

### **Red Deer**

403-347-7733  
5929-48 Ave

### **Calgary**

403-235-2211  
2312-52 Ave

### **Banff**

403-762-2227  
150 Eagle Crescent