



SPECIAL *Event* RENTALS

How to Light the Pilot Light on the Frymaster Deepfryer



Pilot Dial



Temperature Dial

Pilot
(behind round plate)

1. Turn temperature dial to lowest setting.
2. Turn pilot dial to vertical position, press and hold.
3. Light pilot light with barbecue lighter.
4. When there is a steady flame keep pressing for 45 seconds to heat up the thermocouple, then turn pilot light to the thermocouple
5. Turn pilot light to the on position and set heat temperature to desired heat.

Edmonton
780-435-2211
6010-99 Street

Red Deer
403-347-7733
5929-48 Ave

Calgary
403-235-2211
2312-52 Ave

Banff
403-762-2227
150 Eagle Crescent